

INCLUDED COMPONENTS

TOOLS REQUIRED



1/2" & 7/16 SOCKET WRENCH

NOTE:
IF YOU PURCHASED A COMPLETED BROADCAST SPRAYER, FOLLOW THE SPOT SPRAYER MANUAL AND MOUNT KIT ASSEMBLY INSTRUCTIONS BEFORE YOU COMPLETE BOOM ASSEMBLY STEPS.

Boom Assembly (1) 34-140165	Nozzle Elbow (2) G-8230022	Boomless Nozzle Cap (2) G-8253047	Boomless Nozzle (2) BN2BP088RSX and BN2BP088LSX	Gasket (8) G-G00002020	Mounting Plates (2) 31-100332	Flange Nuts (6) 33-100113
Fan Nozzle Cap (3) G-T00100001	Fan Nozzle (3) G-8259494	Nozzle Strainer (5) NS-50	Flush Port Cap (1) G-T00100036	Mounting U-Bolts (2) 33-100394	Boom Upright Brackets (2) 31-100160	1" Bolts (6) 33-100116

SPRAYING SIMPLE **FREE**

MOBILE SPRAY ASSISTANT

INTEGRATE YOUR SPRAY EQUIPMENT AND ACREAGE. CALCULATE YOUR NEEDED LIQUID AND APPLICATION SPEED.

1. PARTS

TOOLS

None

Caps the Flush Port

Place Gasket inside Flush Port Cap.
Push onto end of Boom Assembly and twist to lock.



2. PARTS

TOOLS

None

Installs Nozzle Elbows

Insert Gasket into the Nozzle Elbow.
Push Nozzle Elbow onto one of the open Nozzle Assembly Ports and twist to lock.

NOTE: This step is repeated for each end of the Boom Assembly.



3. PARTS

TOOLS

None

Insert Nozzle Strainer into Nozzle Elbow, then Insert Gasket into Boomless Nozzle Cap.

Press the Boomless Nozzle Cap onto the Nozzle Elbow and twist to lock.

NOTE: This step is repeated for each end of the Boom Assembly.

Attaches Boomless Nozzle Caps



4. PARTS

TOOLS

None

Thread Boomless Nozzle labeled 088RSX onto the right Boomless Nozzle Cap, ensuring the cutout is pointing down.

Repeat for the left Boomless Nozzle labeled 088LSX

NOTE: Each nozzle is labeled: 088RSX for right, and 088LSX for left.

Installs the Boomless Nozzles



5. PARTS

TOOLS

None

Place Fan Tip into Fan Nozzle Cap.

Insert Gasket into Fan Nozzle Cap.

Place Nozzle Strainer into Nozzle Assembly Port.

Press Fan Nozzle Cap onto Nozzle Assembly Port and twist to lock.

Installs 3 Flat Fan Nozzles



NOTE: This step is repeated for each end and center of the Boom Assembly.

6. PARTS

TOOLS

None

Remove the Nuts from the U-Bolts and place the U-Bolts over the pipe of the Boom Assembly.

Insert the U-Bolts through the holes in the Mounting Plates and secure the Nuts with a Socket Wrench.

NOTE: The U-Bolts require a 7/16" Socket Wrench.

Installs Boom Mounting Plates to Boom Assembly

